


HUROM

- 02 Precautions for Safe Use
- 05 Part Names
- 06 Product Specifications /Warranty
- 07 How to Assemble
- 08 How to Operate
- 09 Recipes



BL-C01 SERIES INSTRUCTION MANUAL

- 01** Please make sure that you read the "Precautions for Safe Use" on page 02, and use the product as instructed.
- 02** After reading the Instruction Manual, keep it in a place where it can be readily accessed by anyone.
- 03** Do not use it abroad which has different power supply and voltage.
- 04** The product specifications are subject to change without notice for quality improvement purposes.

PRECAUTIONS FOR SAFE USE

● Precautions for Safe Use

1. Be sure to read the <Precautions for Safe Use>.
2. Make sure you follow the <Precautions for Safe Use>.
3. Warn of potential injury from misuse. Warnings are classified as follows:

- Warning** Failure to comply with the label instructions may lead to serious injury or death.
- Caution** Failure to comply with the label instructions may lead to serious injury or product damage.

- Do not plug in or pull the power cord with wet hands. Failure to follow this instruction may cause electric shock or injury.
- Do not use other power supplies except 220 - 240V AC power supply. Connecting to a different voltage may shorten the motor's lifespan or cause malfunction.
- Plug the power cord correctly, all the way into an outlet. Failure to follow this instruction may cause electric shock or fire.
- Do not forcibly bend, tie, hurt or pull the power cord. Do not place it near a high temperature or a heat, such as gas cooktop. Do not place it on top of any heavy objects, wedge it into a narrow space, or alter it. Doing so may damage the power cord, causing fire or electric shock.
- Never attempt to alter it. Moreover, do not attempt to dismantle or repair it by yourself.
- Do not insert foreign objects, such as a finger or an iron pin, into any cracks or holes in the main body. Contact certified repair centers or our stores if there is any problem with the product. Failure to follow this instruction may lead to fire, electric shock, injury, or malfunction.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard, electric shock, or injury.
- Do not let the main body come in contact with water or splash water over it.
- Make sure that no water or foreign material enters the switch on the product.
- Do not operate the switch with wet hands. Failure to follow this instruction may cause electric shock or fire.
- Do not use the product by connecting it to an outlet where other appliances are connected. Use a dedicated socket. Do not move the product while operating; never insert anything other than hand, utensils, or ingredient inside the container. Failure to follow this instruction may cause injury, accident, or malfunction.

- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Children shall not play with the appliance.
- Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
- Be careful if hot liquid is poured into the the blender as it can be ejected out of the appliance due to a sudden steaming.
- Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.
- Care shall be taken when handing the sharp cutting blades, emptying the bowl and during cleaning.
- Always remove the jug from the motor unit before cleaning. The blade is extremely sharp and could cause serious personal injury. Wash the beaker, cutter blade, other chopping attachments and lid with water.

● Precautions Before Use

- Be sure to follow the instruction to operate it and check whether the appliance works.
- This product was intended to be operated only when the blade unit and container are assembled. Never operate the appliance with the blade unit only. This may cause a serious injury.
- Always make sure that the appliance is placed on a flat surface before use. Failure to follow this instruction may cause injury or malfunction.

● Precautions During Operation

- Refrain from using the appliance in places with risk of fire and high humidity. Failure to follow this instruction may cause injury, malfunction, or fire.
- Before using the product, make sure to check that liquid does not leak from the container and blade unit. It may cause product damage, electric shock, and injury.
- Use utensils such as spatula when taking out the ingredients from the container. Putting your hand inside may cause injury.

- When the appliance makes a "Whoosh" sound while operating, it means chunks of ingredient are stuck between the blades. Remove the chunks and put them back into the container after chopping them into smaller pieces.
 - Do not overload the appliance. It may cause damage due to the overheating of motor.
 - Do not poke the gap in the appliance with chopstick, spoon, or fork or insert materials other than ingredients. Failure to follow this instruction may cause injury or malfunction.
 - Do not lift the container or open the cover while the appliance is being operated.
 - Do not operate the appliance in empty state. This may cause overheating of the motor and lead to early product damage.
 - Do not subject the product to extreme shock or drop it. Failure to follow this instruction may cause electric shock, damage, or fire.
 - The burning smell of rubber transmitted during operation is not a sign of product damage so you can use it without any problem.
- Nonetheless, do not use the appliance for more than 1 minute without pause.

● Precautions After You Used the Product


- In addition, be sure to unplug the power cord by pulling the head of the plug. Pulling the cord may lead to injury, electric shock, or fire.
- Remove the container once the operation is completed.
 - Do not clean the main body of the appliance with water. This may cause damage to the motor and switch or electrocution.
 - Do not put the parts of the appliance (e.g., container, lid) into hot water with temperature of over 40°C.
- Failure to follow this instruction may cause deformation or damage.

● Cleaning and Maintenance

1. Clean the outer surface of the appliance with a sponge soaked in mild detergent.
2. Parts other than the main body are machine-washable or hand-washed.
3. Rinse thoroughly and dry completely.
4. Once the cleaning is over, attach the blade unit to the container before storing the appliance.

※ **Do not use the appliance for more than 1 minute without pause. When using the appliance consecutively, do not use it for more than 3 times in a row within one minute.**

PART NAMES



PRODUCT SPECIFICATIONS / WARRANTY

● Product Specifications

Product Name	Blender	Rated	1minute 3times
Model Name	BL-C01 series	Operating Hour	
Rated Voltage	220-240V ~	Cord Length	0.85 m
Frequency	50 - 60Hz	Motor	A/C
Rated Power	250W	Weight	1.3kg
Consumption		Outward	W113mm
RPM	20,000RPM	Dimension	L 113mm H368 mm

● Warranty

1. **Important :** To better protect your purchase, fill out and mail this form to a local distributor where you purchased the appliance and keep the original receipt. This certifies that the Hurom Power Blender is covered under warranty by Hurom to be free from defects in material construction and workmanship.

2. This warranty does not apply to damages caused by accident, misuse, abuse, commercial use, alteration, failure to follow operating instructions, or damage caused by parts or service unauthorized by Hurom. Damages caused by transportation must be claimed with carrier Hurom. disclaims all responsibilities for consequential damages from incidental losses caused by use of this appliance. Please check the bottom of your Hurom product for a sticker with a barcode. This barcode sticker helps verify a genuine Hurom product and identify the product manufacturing date. Hurom's manufacturer's warranty does not cover products with missing or damaged barcode stickers. Products are to be inspected upon receipt. For service and assistance with technical difficulty, please contact our local customer care center.


Warranty period 1year (household use only)

Seller Hurom LS CO.,Ltd. **MADE IN CHINA**


Product

- 6 -


HOW TO ASSEMBLE




① Place the appliance on a flat surface with its top facing upward.



② Fill the container with the ingredients to blend. Be sure not to exceed the limit of the container, however.




③ Fasten the blade unit to the cap to close.




④ Attach the container by placing it upside down. Rotate the container downward after aligned the [I] signs on the main body and blade unit.

- 7 -

HOW TO OPERATE



① When a click sound is heard when pressing the power switch, the operation starts with [ON] mode.



② When blending is over, press the switch again until a click sound is heard. The appliance will stop and shift to [OFF] mode.



③ Remove the container by rotating it counterclockwise.



④ Detach the blade unit and close the cap. You are now ready to enjoy your drink.

- 8 -

RECIPES

● QUICK RECIPES

COFFEE GRINDING: Put dry, roasted coffee beans into the blender and grind for 20 seconds at high speed.

SWEETCORN BLENDING: Put dry sweetcorn into the appliance and blend for 60 seconds at high speed.

ICE CRUSHING: Put ice cubes and blend for 2 seconds, and then pause for 2 seconds. Keep repeating this until the ice cubes are completely crushed. How to Make Smoothies: Put smoothie ingredients into the blender and blend for 45 seconds at high speed.

CRUSHING ALMONDS: Put almond ingredients into the blender and blend for 15 seconds at high speed.

● RECOMMENDED RECIPES

CHICKPEA AND SWEET PUMPKIN SOUP

[Ingredients that you will use to blend] 100g sweet pumpkin, 30g onion, 10g celery, 50g boiled chickpeas, 10g large spring onion, 200ml chicken stock

[Ingredients that you will use to boil] 100ml whipped cream, 1/2t salt, a pinch of pepper

1. Cube the sweet pumpkin (after peeling and scraping out the seeds), onion, celery, and large spring onion.

2. Put into the container and blend.

3. Boil the blended ingredients on a pot. Add whipped cream, salt, and pepper to finish it.

TIP: Croutons, pumpkin seeds, and sunflower seeds are great for garnish. A drizzle of olive oil will add extra flavor.

CHESTNUT LATTE

[Ingredients that you will use to blend] 6 steamed chestnuts, 150ml milk, 5g nuts, 1T honey, and a pinch of cinnamon powder

1. Blend steamed chestnuts, milk, honey, and nuts.

2. Add honey and cinnamon powder to the blended liquid.

TIP: Add some espresso according to preference.

- 9 -

BASIL SAUCE

[Ingredients that you will use to blend] 20g basil, 100ml fish broth

[Ingredients that you will use to boil] 25g butter, 25g flour, 100ml whipped cream, 1T lemon juice, 1/3t salt, and a pinch of white pepper

1. Blend basil, and fish broth.

2. Mix the blended ingredients with flour, whipped cream, lemon juice, butter and salt over medium heat and boil for 6 minutes.

3. Add white pepper to the soup to finish it.

TIP: You may use vegetable broth instead of fish broth.

Be sure to stir the flour once it is added to the broth. Otherwise, the flour will stick to the bottom.

NATURAL STEW SPICES

[Ingredients that you will use to blend] 1t pollack powder, 1/2t shrimp powder, 1 1/2T anchovy power, and 100g soybean paste

1. Remove the intestines of anchovies.

2. Blend the ingredients and mix thoroughly with soybean paste.

TIP: Shrimp powder sweetens the sauce, so adjust the amount depending on your preference. If you leave the powder for a while before use, the powder does not create as much bubbles when making the sauce.

AVOCADO SMOOTHIE

[Ingredients that you will use to blend] 1/2 avocado, 1 cup frozen blueberries, 100g plain yogurt

1. Blend avocado, frozen blueberries, and yogurt together.

TIP: Add some honey according to your taste.

GREEN JUICE

[Ingredients that you will use to blend] Green vegetables (broccoli, kale, and pak choi), pineapple, ginger, and coconut water

1. Put all the ingredients and blend.

TIP: You may use yogurt instead of coconut water according to your taste.

- 10 -